
Rugged M.2 NVMe SSD Mobile Rack for External 3.5" Bay











MB842MP-B




Weidenweg 21H 47059 Duisburg, Germany Email: support@icydock.co Copyright © ICY DOCK International. All Rights Reserved. 650292 VER 1.0

Cremax Europe GmbH

Package Contents ® Packungsinhalt ® Contenu ® Contenido del paquete ® 包装について ® 包装説明 ® 包装説明









2


MB840M2P-B ▼ Top View





Full Height IO Faceplate











① Note: Please make sure your motherboard supports "PCIe bifurcation" to use dual M.2 NVMe SSDs simultaneously. Check the user manual of the motherboard or contact the motherboard manufacturer for this info. The motherboard will only detect single M.2 NVMe SSD without PCIe bifurcation feature

PCIe Bifurcation Setting

2 Error-proofing Pin to Align M.2 Connector

Installation Guide ® Installationsanleitung ® Guide d'Installation ® Guide de instalación ® 製品の組み込み手順について ® 操作步骤

2

Remove the clear protective film on both sides of the 1mm or 0.7mm thermal pad (depends on your SSD thickness) and then paste it on the tray plate.

M.2 SSD

Make sure your motherboaru and the state of the BIOS menu.

Enter the BIOS menu.


Select EZ/Easy Mode and then click Advance/Classic Mode


Locate PCIe port configuration and then change the setting to x4 x4 or x4 x4 x4 x4

MB840M2P-B & MB842MP-B
▼ Drive Tray Inner View

Press down the rear of the top cover and push towards the guided arrow to open the top cover.

3-2







3-6



(MB842MP-B)











ICY DOCK reserves the right to change product specifications, components, o accessories without prior notice. For the warranty information, please visi www.icydock.com/warrenty.php